

FIG.2




FIG.3




FIG. 4




FIG.5




FIG.6




FIG. 7




FIG.8




FIG.9





FIG.10







FIG.12

(b-1) SETTING OF VEL TARGET OPERATING ANGLE "TGVEL"



12/19

FIG.13

(b-2) SETTING OF VALVE UPSTREAM PRESSURE BASED CORRECTION VALUE "KMANIP"






FIG.14

(b-3) CALCULATION OF VALVE TIMING BASED CORRECTION VALUE "KHOSIVC"



14/19

FIG.15



15/19

FIG.16

(c) SETTING OF VTC TARGET (PHASE) ANGLE "TGVTC"





FIG.17


(d-1) SETTING OF TARGET THROTTLE OPENING "TDTV0"



17/19

FIG.18


(d-2) CALCULATION OF INTAKE VALVE OPENING BASED CORRECTION VALUE "KAVEL"



18/19

FIG.19

(d-3) CALCURATION OF PRESSURE RATIO(P_{m1}/P_a)
AT THE TIME WHEN VEL OPERATES



19/19

FIG.20

(d-4) CALCULATION OF RATIO "WQH0VEL", "RQH0VEL" OF VOLUME FLOW PASSED THROUGH INTAKE VALVE

